



## XA-3P Firmware Update Guide

1. Power on the XA-3P.
2. Navigate through the OLED Menu and select 'Setup'.  
Then, select 'Firmware Update' and select 'Yes'.
3. Connect a mini USB to USB cable from the XA-3P to your PC/Laptop.
4. An empty folder should appear on your desktop and the XA-3P will display 'Paste FW File...' on the OLED screen.
5. Copy and paste the latest firmware file provided into this folder.
6. The OLED screen should display 'Programming...', and the HDCP LED will start flashing.  
**DO NOT REMOVE POWER DURING THIS UPDATE!**
7. After the firmware update has finished, the XA-3P will automatically reboot and this concludes the firmware update.
8. You will be able to check if the firmware update was successful by reading the firmware version the XA-3P displays on the OLED screen whilst it is powering on.