




KS-2 Media Station

Quick Installation Guide | ENGLISH





FCC

Federal Communication Commission interference statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help.

RF Exposure Warning

The equipment complies with RF exposure limits set forth for an uncontrolled environment. The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

FCC Caution

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference and
- (2) this device must accept any interference received, including interference that may cause undesired operation

This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.



CE

Hereby, AREC Inc., declares that this Media Station is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

CB

CB

CAUTION

Danger of explosion if battery is incorrectly replaced.

Replace only with the same or equivalent type.

- the ventilation should not be impeded by covering the ventilation openings with items, such as newspapers, table-cloths, curtains, etc.:
- no naked flame sources, such as lighted candles, should be placed on the apparatus;
- attention should be drawn to the environmental aspects of battery disposal;
- the use of apparatus in tropical climates.

the instructions for use shall state that the apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus.





Introduction

Featuring a compact and stand-alone design, AREC KS-2 Media Station consists of diverse features and functionality, including dual-signals capturing, recording synchronously, codec, streaming online, live broadcasting, and web-based monitor page, providing complete lecture capture solution.

Specifications


Product Name	Media Station
Model Name	KS-2
Dimension	354mm(L) x 188.2mm(W) x 46mm(H)
Weight	1320g
Power Requirement	12V/2A
Power Consumption (Max.)	24W (Max.)
Operating Temperature / Humidity	0°C ~ 50°C / 90%
Maximum normal load description	Insert 2 video signals (either HDMI or VGA input).Using external USB flash to record the transcoded video / audio. And output the transcoded video /audio to both HDMI and VGA port.

Package Contents




Product Appearance

■ Front




■ Back




NO.	Name	Brief introduction
1	Remote Control receiver	Remote Control receiving area
2	Led light	Record / Power
3	Power	Power on / off devices
4	USB port	Export document by driving USB flash drive into USB port / Firmware update through USB disk
5	Power port	12V / 2A
6	Video input source	VGA / HDMI cables input source
7	Video output source	VGA / HDMI cables output source
8	Audio input source	Line / Mic audio input source
9	Audio output source	Line audio output connect to amplifier
10	Hard drive port	USB flash drive
11	Network WAN port	Connect to network
12	Setting LAN port	Connect to setting PC
13	RS-232	RS-232 control signal connector
14	Reset	Restoring devices to its factory default state

Remote Controller



NO.	Name	Brief introduction
1	Power	Power on / off devices
2	Info	Show information
3	Record	Start video recording
4	Play	Start or resume video play
5	Stop	Stop video play / Stop video recording and exit
6	Record Layout	Switch record layout
7	Export	Export latest video to USB drive
8	Select:Up / Down / Left / Right	Navigate menu
9	OK	Select and execute option
10	Back	Cancel option / Return to previous view
11	Menu	Go to main menu screen

Connection



Connection


NO.	Name	Brief introduction
1	Power	Power connection
2	Video input	Video input for VGA or HDMI cables. For example: Connected to notebook or document cam, DV camcorder.
3	Video output	Video output for VGA or HDMI cables. For example: Connected to projector or TV.
4	Audio input	Audio input for Line or Mic. For example: Connected to amplifier or microphone.
5	Audio output	Audio output for Line or Mic. For example: Connected to amplifier or Speaker
6	Hard drive	USB flash drive.
7	Network WAN port	Connected to network for Internet video streaming.
8	Setting LAN port	Connected to setting PC.
9	RS-232	Connected to RS-232 device for control command.
10	Export USB hard drive.	Driving USB flash drive into USB port to export document or update firmware.

Product setup


Initial installation

Connect PC to setting LAN port, and input 192.168.11.254 in the browser page.

Step 1 : Log in **System Administration** with default user ID **admin** and password **admin**.



Step 2 : Set up time of host machine by selecting settings in **time** tab in **System Information**.



Step 3 : Plug USB drive to backside USB port and set up local storage. Click  to format your hard disk after first installation.

Please check both [Enable local storage](#) and [Cycling Record](#) checkbox. Click [Apply](#) to exit the page after setup.

The screenshot shows the Aneco System Administration interface. On the left sidebar, 'Local Storage Setting' is highlighted with a red box and the number 1. The main content area has a 'Storage Device' table with the following data:

Status	Interface	Disk Name	Capacity	Free Space	Manufacturer
Mounted	USB	Ultra Fit	28.19 GB	28.02 GB	SanDisk

Below the table is the 'Storage Setting' section, which includes two checked checkboxes: 'Enable Local Storage' and 'Cycling Record'. A dropdown menu shows 'Select disk : USB1'. The 'Apply' button is highlighted with a red box and the number 4. A red box with the number 2 highlights the USB icon in the table, and a red box with the number 3 highlights the checkboxes.

Step 4 : Click Logout to exit setting page.

The screenshot shows the Aneco System Administration interface. The 'Logout' link in the top right corner is highlighted with a red box. The rest of the interface is the same as in the previous screenshot, but the 'Apply' button is no longer highlighted.

Step 5 : Plug DV or PC to Video input port, you may see the image on connected display.

Recommendations for your hard disk:

1. Please install hard disk of capacity greater than 64G if you want to record full HD images as the host system can record videos up to 8 hours in one shot.
2. A poor quality hard disk may lead to host reading failure. Please make sure the following message prompts when a hard disk is inserted.



Battery Safety Messages

- Please store the battery at cool and dry places.
- Please do not randomly discard used batteries; please collect the batteries and drop them at specific recycling locations.
- If the product is not used for long periods of time, please remove the batteries from the product. In addition, please also remove the depleted batteries to avoid battery leakage or corrosion which may damage the remote control.
- Please do not mix new and old batteries together.
- Please use the DURACELL alkaline batteries recommended by the original manufacturer; avoid using different types of batteries.
- Please do not throw the batteries into fire as they may explode or have leakage.
- Please do not short-circuit the electrodes in the battery.

Important Security Policy

■ Precautions

1. Please open the product package carefully; we commend you keep this packaging for future transport, storage or maintenance use.
2. There are no switches or adjustment buttons required for operation inside this product, so for your safety, please do not open the casing on your own, or vigorously rotate, shake or use any other inappropriate ways to operate this product in order to avoid electrical shocks and voiding the warranty. You can contact a local dealer directly if you have any questions.
3. Heat will be generated during the use of this product; therefore there must be sufficient ventilation for the temperature of the unit to remain at a stable status. So please use the product under normal environments to prolong the usage life, and avoid installing it in the following environments.
 - Locations that are unstable or have incomplete planes
 - Locations with powerful magnetic fields
 - Locations where it is damp or may have water leakage
 - Locations that are too hot, close to heaters and air hoses, or be exposed to direct sun light for long periods of time
 - Locations that are dusty
 - Locations where there are possible shocks
 - Locations close to power amplifiers
4. If you notice smoke or odor coming from the product, please quickly remove the power cable and send it to a maintenance center for processing.
5. To avoid electrical shock, the plug of the adapter should be stably and completely inserted into the power outlet and cannot be exposed; it must also have sufficient capacity to withstand the current transmission. Please do not plug the adapter into the power outlet before connecting the cable in order to avoid danger.
6. If not used for long periods of time, please unplug the power plug, and to ensure electrical safety, when unplugging the adapter, please hold the plastic part of the adapter with dry hands and then unplug the adapter. Please properly connect the cables according to the printed instructions on the installation manual and the machine to ensure optimized usage effects.



AREC Inc.© All Rights Reserved 2016. | www.arec.com
All information contained in this document is Proprietary



Made in Taiwan
Date : 2016.06.01