

Installation manual

ELPMB68 Ceiling Mount

V12H006AE0

Safety precautions

Failure to comply with these safety precautions could result in death or serious injury.

At least two qualified people should perform the installation. Personal injury and/or property damage can result from dropping or mishandling the projector.

If mounting to ceiling studs, make sure that the mounting screws are anchored into the centre of the ceiling studs. Use of an edge-to-edge stud finder is recommended.

Electrical shock hazard

Always turn off, disconnect, and disengage all power sources to the projector before servicing.

Be aware of the mounting environment. If drilling and/or cutting into the mounting surface, always make sure that there are no electrical wires in the wall.

Do not install near sources of high heat. Do not install on a structure that is prone to vibration, movement or has a chance of impact.

Maximum projector weight limit is 45kg (99 lbs).

Tools included

5mm hex key



1. Position and securely fasten the ceiling plate to the ceiling.



2. Insert the calibration device into the ceiling plate.



3. Position the projector adaptor plate with adjustable arms on the bottom side of the projector.



4. Secure the adjustable arm plate to the projector by positioning the plate's screws with the designated holes on the bottom of the projector.



5. Secure the projector to the ceiling mount with the two setscrews.



6. Calibrate and position the mount with the four adjustment knobs.



7. In the case of heavy loads, use a hex key to calibrate the projector position.



8. Tighten the four button screws to eliminate vibration or movement during operation.