

Safety precautions

Failure to comply with these safety precautions could result in death or serious injury.

At least two qualified people should perform the installation. Personal injury and/or property damage can result from dropping or mishandling the projector.

If mounting to ceiling studs, make sure that the mounting screws are anchored into the centre of the ceiling studs. Use of an edge-to-edge stud finder is recommended.

Electrical shock hazard

Always turn off, disconnect, and disengage all power sources to the projector before servicing.

Be aware of the mounting environment. If drilling and/or cutting into the mounting surface, always make sure that there are no electrical wires in the wall.

Do not install near sources of high heat. Do not install on a structure that is prone to vibration, movement or has a chance of impact.

Maximum projector weight limit is 45kg (99 lbs).

Tools required

5mm hex key



1. Position and securely fasten the ceiling plate to the ceiling.



2. Insert the column into the ceiling plate and lock it into place using the hexagonal wrench.



3. Position the projector adaptor plate with adjustable arms on the bottom side of the projector.



4. Secure the adjustable arm plate to the projector by positioning the plate's screws in the designated holes on the bottom of the projector.



5. Secure the projector to the ceiling mount with the two set screws.

ELPMB68 Ceiling Mount and white plastic cover sold separately.

Technical specifications are subject to change.